

APPLICATION INSTRUCTIONS FOR
Materials by the yard
Available width: 28" (71cm)



t (001) 586.772.5551 f (001) 586.772.6237
e info@stahlsinternational.com w StahlsInternational.com

Thermo-Adhesive™

Create custom appliqué fabrics with this patented adhesive for in-house application to any fabric. (PU, 127 micron [+/-10%])



PREHEAT & POSITION

It is pertinent to preheat fabric patch before application. Press for 5-10 seconds to remove moisture, chemical treatment and wrinkles from the application area.

Position weeded design onto garment and press firmly until all edges are smooth. Cover with Kraft Paper or Reusable Cover Sheet to protect garment and image.



TACK IMAGE

Tack adhesive side down with fabric/patch facing upward for 3 seconds. Allow to cool completely, remove paper and trim excess adhesive.

Temperature: 345°-350°F; 172°-175°C

Time: 3 seconds

Pressure: medium (#4 on Hotronix®)



HEAT APPLY

Position fabric/patch, cover and heat apply.

Temperature: 345°-350°F; 172°-175°C

Time: 5-15 seconds

Pressure: medium (#4 on Hotronix®)

NOTE: allow sufficient time for heat to penetrate fabric/patch.



NOTE: if using material that tends to fray, edges should be sewn with a zig-zag stitch after applying the adhesive.

All technical information and recommendations are based on tests we believe to be reliable. However, we cannot guarantee performance for conditions not under manufacturer's control. Before using, please determine the suitability of product for its intended use. The user assumes all risk and liability whatsoever in connection with the use of this product. Seller's and manufacturer's only obligation shall be to replace such quantity of the product proved to be defective by manufacturer.

CAD-CUT, Pressure Sensitive Poly-TWILL, & Hotronix are trademarks & ® trademarks of GroupeSTAHL™ with one or more patents or patents pending.
© Stahls' International™ 2012 - All International Rights Reserved