

APPLICATION INSTRUCTIONS FOR  
**Materials by the yard**  
Available width: 28" (71cm)



t (001) 586.772.5551 f (001) 586.772.6237  
e info@stahlsinternational.com w StahlsInternational.com

## Thermo-Adhesive™

Create custom appliqué fabrics with this patented adhesive for in-house application to any fabric. (PU, 127 micron [+/-10%])



### PREHEAT & POSITION

It is pertinent to preheat fabric patch before application. Press for 5-10 seconds to remove moisture, chemical treatment and wrinkles from the application area.

Position weeded design onto garment and press firmly until all edges are smooth. Cover with Kraft Paper or Teflon® Sheet to protect garment and image.



### TACK IMAGE

Tack adhesive side down with fabric/patch facing upward for 3 seconds. Allow to cool completely, remove paper and trim excess adhesive.

Temperature: 345°-350°F; 172°-175°C

Time: 3 seconds

Pressure: medium (#4 on Hotronix®)



### HEAT APPLY

Position fabric/patch, cover and heat apply.

Temperature: 345°-350°F; 172°-175°C

Time: 5-15 seconds

Pressure: medium (#4 on Hotronix®)

NOTE: allow sufficient time for heat to penetrate fabric/patch.



NOTE: if using material that tends to fray, edges should be sewn with a zig-zag stitch after applying the adhesive.

Toda la información técnica y recomendaciones están basadas en pruebas que consideramos confiables. Sin embargo, no podemos garantizar el desempeño en condiciones fuera del control del fabricante. Antes de usar, determine el propósito para el que va a usar el producto. El usuario asume todos los riesgos y responsabilidades en relación al uso de este producto. La obligación del fabricante o vendedor es reemplazar la cantidad de producto que resulte defectuoso.

CAD-CUT, Poly Twill de presión sensitiva, & Hotronix son marcas registradas de GroupeSTAHL™ con una o más patentes pendientes.  
© Stahls' International™ 2011 Todos los derechos internacionales reservados.